

General:

(A) Install over solid decking with housewrap underlay.

(B) Most trims are installed prior to panels.

(C) Fasten panels with panel clips, clipping to panel hem 2' on center, and then lock the next panel's batten over that hem. BBM Board & Batten is typically installed vertically, from left to right or right to left. It can also be installed horizontally, but requires (1) Offset cleat at the bottom to lock onto. (2) Joint trim or special detail for walls wider than 20'.

